



Solar Occultation Satellite Science Team Meeting

Williamsburg, May 6-7 2003



Solar Occultation Retrieval Algorithm Development

Jerry Lumpe

Computational Physics, Inc.

Cora Randall

LASP, Univ. of Colorado

Karl Hoppel

Naval Research Laboratory



Objectives



- Quantitative evaluation/comparison of current POAM II/III & SAGE II/III retrieval algorithms.
- Develop optimal approach to the UV/Vis solar occultation retrieval problem by:
 - Synthesizing current approaches
 - Exploring new ones.
- Apply resulting algorithm to POAM and SAGE data.



UV/Visible Solar Occultation



A common POAM/SAGE algorithm is possible because of the fundamental similarity of the instruments:

- **Same basic measurement/viewing geometry.**
- **Common spectral range.**
- **Similar spatial field of view.**

⇒ **The fundamental forward model & retrieval problem is identical for these four instruments.**

Only significant difference is spectral sampling.

POAM II/III – 9 channels

SAGE II – 7 channels


SAGE III – 86 channels



Motivation - O₃ Retrievals



LASP



Comparison of
POAM III-SAGE II
retrieved O₃ &
600-nm OD.



Forward Model



Fundamental measurement is slant optical depth:

$$\delta_{meas}^i(z_{\perp}) = \sum_{\alpha} \delta_{\alpha}^i(z_{\perp}) \quad (i = 1, N_{\lambda})$$

$$\delta_{\alpha}^i(z_{\perp}) \equiv -\ln \int_{\Delta\nu_i} d\nu Q_i(\nu) I_o(\nu) e^{-\int_{z_{\perp}} ds k_a(\nu, z(s), T(s), P(s))}$$

$$\delta_{meas}^i(z_{\perp}) = \delta_{aer}^i(z_{\perp}) + \sum_{\alpha} \sigma_{\alpha}^i(T, P, N_{\alpha}) N_{\alpha}(z_{\perp})$$

$$N_{\alpha}(z_{\perp}) = \int_{z_{\perp}} ds n_{\alpha}(s) \quad (\alpha = \text{RS, aer, O}_3, \text{NO}_2, \text{H}_2\text{O, O}_2)$$



Retrieval Problem



We need to invert

$$y = F(x)$$

where

$$y = \left[\delta_{meas}^1(z_{\perp}), \dots, \delta_{meas}^{N_{\lambda}}(z_{\perp}) \right]$$
$$x = \left[n_{O_3}(z), n_{NO_2}(z), n_{H_2O}(z), n_{mol}(z), k_{aer}(\lambda, z) \right]$$

Various approaches are possible:

- 1-step or 2-step (spectral/spatial inversion).
- Simultaneous or sequential species separation.
- Many numerical inversion techniques exist.
- Handling of Rayleigh and aerosol scattering terms.



POAM/SAGE Algorithm Summary



Instrument	Overall Approach	Spectral Inversion	Spatial Inversion	Rayleigh Scattering	Aerosol Spectral Dependence
POAM II	<u>Two Step</u> 1. Spectral 2. Spatial	Simultaneous solution. Nonlinear Opt. Est.	Linear Opt. Est.	Fixed to UKMO	Global nonlinear fit
POAM III	“	“	“	Retrieved from UV channels (> 30 km)	“
SAGE II	“	Sequential, Iterative for O ₃ , NO ₂ , Aer H ₂ O off-line	Modified Chahine	Fixed to NCEP	Mie scattering kernels
SAGE III	“	Simultaneous O ₃ /NO ₂ Residual Aer H ₂ O off-line	“	Fixed to NCEP (A band ?)	Taken directly from residual optical depth



Proposed Work



- **Develop generalized forward model.**
- **Implement generalized retrieval algorithm (heritage from POAM* and StOLSS).**
- **Evaluate algorithm using multiple methods:**
 - **Simulations (range of atmospheric conditions).**
 - **Coincident POAM/SAGE measurements.**
 - **Comparison with correlative measurements.**

* Lumpe, *et al.*, *J. Geophys. Res.*, 107(D21), 4575, 2002.



Forward Model Capability



- Atmospheric transmission from the ground to 90 km.
- Full treatment of atmospheric refraction.
- Arbitrary spectral sampling.
- Efficient path integration routines, incorporating horizontal gradients (non-spherical symmetry).
- Up to date spectroscopy.
- Full line-by-line calculation for O₂/H₂O.
- Look up tables of effective cross sections: $\sigma_{\alpha}^{\lambda_i}(T, P, N_{\alpha})$
- Variety of aerosol and cloud models.




H₂O Spectroscopy



LSP

POAM III Channel 8 H₂O Cross Section

$$\sigma_{H_2O}^8(T, P, N_{H_2O})$$





Generalized Retrieval Algorithm



Current capabilities:

- Arbitrary spectral sampling/vertical resolution.
- Simultaneous retrieval of multiple (variable) species using Optimal Estimation.
- 1-step or 2-step inversion.
- Detailed retrieval diagnostics (avg kernels, errors).

New approach will allow:

- Simultaneous or sequential species retrievals.
- Alternative numerical approaches inversions.
- Alternative aerosol parameterizations.



Retrieval Characterization



We can characterize many aspects of the retrieval algorithm using the retrieval averaging kernels:

$$A_{\beta, z_j}^{\alpha, z_i} \equiv \frac{\partial \hat{x}(\alpha, z_i)}{\partial x(\beta, z_j)} \quad (\alpha, \beta = \text{RS, aer, O}_3, \text{NO}_2, \text{H}_2\text{O, O}_2)$$


- Vertical resolution from diagonal elements $(\alpha = \beta)$
- Species correlation from off-diagonal elements $(\alpha \neq \beta)$
- Spectral resolution of aerosol retrievals $(\alpha = k_{aer}^{\alpha}; \beta = k_{aer}^{\beta})$
- Information content (*a priori* bias)



POAM Species Correlations



A priori dependence and species correlation in gas retrievals.






POAM Aerosol Spectral Resolution



LSP

$$\ln \delta_{aer}(\lambda) = \mu_o + \mu_1 \ln \lambda + \mu_2 \ln^2 \lambda$$





Some Issues to Address



-
- **UT/LS O_3 (aerosol separation issues).**
 - **Aerosol parameterization and spectral dependence.**
 - **Coupling of blue channel aerosols and NO_2 .**
 - **SAGE II H_2O (aerosol/ O_3 interference, spectroscopy).**
 - **SAGE III retrieval issues (species coupling, etc).**
 - **O_2 A band retrievals (compare SAGE III & POAM III).**
 - **Cross section and spectroscopy issues.**
 - **Full retrieval characterization and error analysis.**



Summary




-
- **We propose to develop general forward model and retrieval algorithms for UV/Vis solar occultation instruments.**
 - **These algorithms will allow us to study a number of important retrieval issues which impact the current agreement between POAM and SAGE data sets.**
 - **Use of a common algorithm implementing an optimal retrieval approach could improve the consistency of these data sets in the future.**



Primary Scattering & Absorption Features for POAM/SAGE



LSP






POAM Spectral Sampling (9 channels)



LSP






SAGE II Spectral Sampling (7 channels)



LASP





SAGE III Spectral Sampling (87 channels)



LSP

